#### MIR-045/MIR-45BT

### **MIRROR OPERATION:**

- 1. The LCD display will automatically turn ON when there is a video signal on the CAMERA input
- 2. The AUX input will turn ON when there is a video signal on the AUX input
- 3. A video signal on the CAMERA input will always override an AUX input

#### MIR-45BT ONLY

## **BLUETOOTH OPERATION CONNECTING YOUR DEVICE:**

- 1. Enable Bluetooth search on your device
- 2. Select the KV-4248 when it is found on your device
- 3. The mirror and device will pair
- 4. Once paired, the mirror will have a Bluetooth icon appear

#### DISCONNECTING YOUR DEVICE FROM THE MIRROR:

- 1. Turn the Bluetooth OFF on your device or remove/forget KV-4248 from your paired devices
- 2. If your device is 30ft (10 Meters) from the mirror, you will automatically be disconnected
- 3. To reconnect, simply turn the vehicle OFF, then back ON. If you have removed the mirror from your device, see Connecting your device

# **CALLER ID, ANSWERING AND ENDING CALLS:**

- 1. Caller ID will automatically be displayed on the LCD display when receiving a call
- 2. To answer a call, press the M/OK button
- 3. To End a call or reject a call, press the button

# **AUDIO CONTROL:**

- 1. Volume adjustment is controlled by your connected device
- 2. Pause
- 3. Track UP
- 4. Track DOWN
- 5. Play (Hold for 2 seconds) M/OK

SCREEN SIZE	4.5"
DISPLAY RESOLUTION	480(H) X 272(V)
OPERATING VOLTAGE	9-16 Volts
CURRENT DRAW	0.04A (MIR-045) 0.06A (MIR-45BT)
VIDEO SIGNAL	PAL/AUTO/NTSC

MIR-045 MIR-45BT REAR VIEW MIRROR

CONGRATULATIONS ON YOUR CHOICE OF A CRIMESTOPPER UNIVERSAL REAR VIEW MIRROR. THIS BOOKLET CONTAINS ALL OF THE NECESSARY INFORMATION FOR CONNECTING AND USING YOUR MIRROR. IF ANY QUESTIONS SHOULD ARISE, CONTACT YOUR INSTALLATION FACILITY OR CHECK OUT THE KNOWLEDGE BASE AT WWW.CRIMESTOPPER.COM



1230-62201-01-A QUICK INSTALL

# MIR-045 MIR-45BT





